



ROBOSUIT™ INSTALLATION INSTRUCTIONS FOR THE EPSON G3 ROBOT

PRIOR TO INSTALLING THE ROBOSUIT™, CLEAN THE ROBOT SURFACE—ESPECIALLY IF THE ROBOT HAS BEEN IN OPERATION WITHOUT ANY EFFECTIVE PROTECTION.

1. DISCONNECT ANYTHING THAT WILL INTERFERE WITH INSTALLATION.
2. MOVE THE ARM TO ITS HOME POSITION.
3. OPEN ALL SEAMS, ZIPPERS AND SNAPS ON SUPPLIED COVERS.
4. INSTALL THE STATIONARY BASE COVER.
5. ATTACH THE ADHESIVE BACKED VELCRO TO THE INNER ARM AT AXIS 1 AND 2.
6. INSTALL THE INNER ARM SUIT PIECE.
7. INSTALL THE PVC FITTING ON THE TOP OF THE OUTER ARM OVER THE Z AXIS OPENING.
8. INSTALL THE OUTER ARM SUIT PIECE.
9. INSTALL THE BELLOW STACK ON THE Z AXIS SHAFT.
10. INSTALL THE INTERCONNECTING ROBOT ARM CABLE SLEEVE AND TOOL AIR LINE SLEEVE.
11. THE ROBOSUIT IS NOW INSTALLED, SLOWLY MOVE ALL AXES AT NO MORE THAN 25% SPEED, AND CORRECT ANY SUIT MISALIGNMENT.

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT ROBOWORLD.