

Omron TM Robosuit® Installation Instructions

Begin installation at the stationary base and work upward toward the tool flange.

12-pc Robosuit[®]: 7-component covers, 5-ring retainers



Wrist and Tool Flange Detail

